

ПЕРЕД ПЕРВЫМ ВКЛЮЧЕНИЕМ

Встраиваемый телевизор для кухни

- Проверьте подключение к сети электропитания. Для проверки убедитесь, что горит светодиодный индикатор на блоке питания и на передней панели телевизора.
- В комплекте поставляется пульт, **защищённый от брызг и струй воды, но не от погружения (степень защиты IP66)**. Пульт оснащён элементом питания стандарта **CR2032**. В некоторых случаях пульт может не комплектоваться батарейками в связи с требованием безопасности при авиатранспортировке.
- Для запуска видео или фото файлов с USB носителя используйте кнопку Enter (выбранный файл будет воспроизводиться в окне предварительного просмотра) и кнопку Play для начала воспроизведения во весь экран.

PRIOR TO FIRST USE / FAQ

Cabinet Door TV for Kitchen

- Check mains power connection. Make sure that LED, on the power supply adapter and on the TV front panel, is ON.
- There is a remote control included in the standard package. **The remote is waterproof, and it has IP66 protection ranking (protection against water jets — don't immerse in water!).** Remote control works with **CR2032** battery type. Batteries for remote control may be absent due to air transportation restrictions.
- To start video or photo files from a USB memory stick or HDD, please use “Enter” button to highlight files and then “Play” button to start playback in full screen mode.